



Acousstop Equitile Panel Installation & Care Guide

1-Product Snapshot



Elegant & aesthetics



Impact Resistance



Low Formaldehyde



High Density Exterior Grade MDF



Moisture Resistance & Fire
Retardant



Anti-Fungal



Black Acoustical Fleece



Up to 6-10% Open Area

2. Storage & Handling



Before You Start

- Lay the panels flat on a clean, dry, and level surface to prevent warping.
- Place a soft, non-abrasive material (like foam sheets or fabric) between each panel to avoid scratches.



Avoid Compression

- Avoid stacking too high to prevent compression or damage to the lower panels. (Max 800mm)
- Keep in a dry, temperature-controlled area to prevent moisture absorption or deformation.

3. Installation

Panels can be installed on walls or ceilings using various profile types (Z-Profile, J-Profile, T15 & T24). Ensure the surface is clean, level, and dry before mounting.



Option A – Z-Profile

1. Mark level lines on the wall.
2. Fix Z-Profiles to the wall.
3. Engage each panel onto the Z-Profile.
4. Keep panel gaps consistent.



Option B – Velcro

1. Mark your layout on the wall.
2. Apply industrial Velcro strips to wall and panel.
3. Press panel firmly into place for full adhesion.

Note: Mounting methods depend on the product profile and project instructions. Follow site specifications for fixing hardware and spacing.

4. Care & Cleaning

Regular Maintenance

Clean twice monthly with soft brush, microfiber cloth, or vacuum. Dust reduces sound absorption and causes discoloration.

Spot Cleaning

Blot gently with damp cloth. Use wood-safe cleaner sparingly—avoid liquid seeping into backing.

What NOT to use

Avoid harsh chemicals, abrasive pads, bleach, ammonia, solvents, or high-pressure cleaning. Never repaint panels.

Environment

Keep away from direct water. Maintain 40-60% humidity. Avoid HVAC vents and heat sources.

5. Do's & Don'ts (Quick Reference)



Do

- Clean twice monthly.
- Use soft brush, cloth, or vacuum.
- Maintain 40-60% humidity.
- Keep away from water.
- Use wood-safe cleaner sparingly.



Don't

- Use harsh chemicals or abrasives.
- Expose to water or high humidity.
- Apply high-pressure cleaning.
- Repaint or refinish panels.
- Place near HVAC vents/heat.
- Ignore dust buildup.

6. Help & Support

India

contactindia@hillpointglobal.com

Dubai

contactdubai@hillpointglobal.com

Qatar

contactqatar@hillpointglobal.com

Saudi Arabia

contactsaudi@hillpointglobal.com