



Acousstop Mac Tile Panel Installation & Care Guide

1-Product Snapshot



Elegant & aesthetics



Reduces reverberation and echo;
improves speech intelligibility



High Density Exterior Grade MDF
with black acoustical fleece



Moisture resistant, fire retardant,
anti-fungal, low formaldehyde



Impact resistant with up to 15%
open area



Variety of sizes and shades

2. Storage & Handling



Before You Start

- Keep panels flat on a clean, dry surface
- Use horizontal stacking method
- Store in dry indoor location
- Acclimatize panels 24-48 hours before installation



Avoid Compression

- Limit stack height to prevent damage
- Ensure good air circulation
- No leaning or bending

3. Installation

Panels are designed for ceiling installation only. Ensure the surface is clean, level, and dry before mounting.



Option A – T-15 Grid

1. Install T-15 grid system on ceiling
2. Ensure grid is level and secure
3. Place panels into grid framework
4. Keep panel gaps consistent



Option B – T-24 Grid

1. Install T-24 grid system on ceiling
2. Ensure grid is level and secure
3. Place panels into grid framework
4. Keep panel gaps consistent

Note: Mounting methods depend on the product profile and project instructions. Follow site specifications for fixing hardware and spacing.

4. Care & Cleaning

Regular Maintenance

Use a soft brush, microfiber cloth, or feather duster. Lightly dust the surface from top to bottom.

Vacuum Cleaning

Use a vacuum cleaner with soft brush attachment. Keep suction low. Do not press hard on the panel surface.

Spot Cleaning

Use a clean, white cloth lightly dampened with water and mild neutral detergent. Blot gently (do not rub). Allow to air dry naturally.

What NOT to use

Do not soak the panel. Avoid bleach, alcohol, ammonia, or solvents. Do not scrub aggressively.

5. Do's & Don'ts (Quick Reference)



Do

- Clean panels regularly with soft materials.
- Maintain indoor humidity at 40-60% RH.
- Ensure good air circulation.
- Fix leaks immediately (AC, roof, or plumbing).



Don't

- Soak the panel or use harsh chemicals.
- Expose to direct contact with water.
- Install in wet areas (bathrooms, kitchens without ventilation).
- Scrub aggressively or use abrasive materials.

6. Help & Support

India

contactindia@hillpointglobal.com

Dubai

contactdubai@hillpointglobal.com

Qatar

contactqatar@hillpointglobal.com

Saudi Arabia

contactsaudi@hillpointglobal.com