



AcoustoStop Perf Panel Installation & Care Guide

1-Product Snapshot



Elegant & aesthetic modular panels designed for noise control.



Reduces reverberation and echo; improves speech intelligibility.



High Density Exterior Grade MDF with black acoustical fleece.



Moisture resistant, fire retardant, anti-fungal, low formaldehyde.



Impact resistant with up to 15% open area.



Finish options: Laminate, Veneer, Paint.

2. Storage & Handling



Before You Start

- Keep panels flat on a clean, dry, level surface to prevent warping.
- Use protective layering (foam sheets or fabric) between panels to avoid scratches.
- Protect from moisture.



Avoid Compression

- Don't stack too high (Max 800mm) to prevent compression or damage.
- Store in a dry, temperature-controlled area.
- No leaning or bending.

3. Installation

Panels can be installed on walls or ceilings. Ensure the surface is clean, level, and dry before mounting.



Option A – Z-Profile

1. Mark level lines on the wall.
2. Fix Z-Profiles to the wall.
3. Engage each panel onto the Z-Profile.
4. Keep panel gaps consistent.



Option B – H-Profile

1. Mark your layout on the wall/ceiling.
2. Fix H-Profiles to the surface.
3. Slide panels into the H-Profile channels.
4. Ensure proper alignment.



Option C – Nailing

1. Mark your layout on the wall.
2. Use headless nails to fix panels.
3. Ensure nails are flush with surface.
4. Maintain consistent spacing.

Note: Mounting methods depend on the product profile and project instructions. Follow site specifications for fixing hardware and spacing.

4. Care & Cleaning

Regular Maintenance

Clean regularly (twice a month) with a soft brush, microfiber cloth, or vacuum. Dust buildup reduces sound absorption.

Spot Cleaning

Blot gently with a damp cloth. Use wood-safe cleaner if needed. Ensure no liquid seeps into backing.

What NOT to use

Avoid harsh chemicals, abrasive pads, or high-pressure cleaning. Do not repaint or refinish panels.

Environment

Keep away from direct water or excessive humidity. Ideal indoor humidity is 40-60%. Avoid placing near HVAC vents or heat sources.

5. Do's & Don'ts (Quick Reference)



Do

- Clean panels regularly (twice a month minimum).
- Use only soft brushes or microfiber cloths.
- Maintain indoor humidity at 40-60%.
- Inspect panels periodically for damage.



Don't

- Use harsh chemicals or abrasive cleaners.
- Expose to direct water or excessive humidity.
- Repaint or refinish the panels.
- Ignore dust buildup (reduces performance).

6. Help & Support

India

contactindia@hillpointglobal.com

Dubai

contactdubai@hillpointglobal.com

Qatar

contactqatar@hillpointglobal.com

Saudi Arabia

contactsaudi@hillpointglobal.com