



Acousstop Sof Fluted Panel Installation & Care Guide

1-Product Snapshot



Polyester fiber panels with smaller grooves for elegant design.



Reduces echo and reverberation; improves speech intelligibility.



Moisture resistant, stain & water repellent fabric with acoustical core.



Fire rated Class B; absorbs 85% of sound.



Cleanable and easy to maintain.



Best acoustical performance for various spaces.

2. Storage & Handling



Before You Start

- Stack on clean, dry, flat surface to prevent deformation.
- Use moisture barrier or plastic sheets for protection.
- Store in temperature-controlled environment.



Avoid Compression

- Don't stack too high; excessive weight affects acoustic performance.
- Stack horizontally to avoid bending or warping.
- No leaning.

3. Installation

Panels can be installed on walls or ceilings. Ensure the surface is clean, level, and dry before mounting.



Option A – Suspension Hanging System (Ceiling)

1. Mark ceiling layout.
2. Install suspension hardware.
3. Hang panels securely.
4. Ensure level alignment.



Option B – Direct Mounting (Wall)

1. Mark wall layout.
2. Apply synthetic rubber adhesive to wall and panel back.
3. Press panel firmly into place.
4. Allow adhesive to cure fully.

Note: Mounting methods depend on the product profile and project instructions. Follow site specifications for fixing hardware and spacing.

4. Care & Cleaning

Regular Maintenance

Clean weekly with soft brush vacuum attachment or lint roller.

Spot Cleaning

Blot spills with damp cloth. Use mild soap and water for stains.

What NOT to use

Avoid abrasive pads, harsh chemicals, or high-pressure cleaning. No cigarette smoke or heavy kitchen smoke exposure.

Environment

Maintain good HVAC filters and air purifiers. Avoid bumping or heavy items against panels.

5. Do's & Don'ts (Quick Reference)



Do

- Clean panels weekly with soft tools.
- Use air purifiers and maintain HVAC filters.
- Blot spills immediately with damp cloth.
- Schedule professional cleaning for commercial spaces.



Don't

- Use harsh chemicals or abrasive cleaners.
- Expose to smoke, moisture, or heavy impacts.
- Rub stains (blot only).
- Place heavy items against panels.

6. Help & Support

India

contactindia@hillpointglobal.com

Dubai

contactdubai@hillpointglobal.com

Qatar

contactqatar@hillpointglobal.com

Saudi Arabia

contactsaudi@hillpointglobal.com